

INSTRUCTIONS FOR INSTALLATION OF OUTDOOR APPLIANCES **MANUFACTURED BY RAIMAR LTD**

Thank you for choosing Raimar and ordering a Bulgarian product!

Customer feedback is extremely important to us. If you have questions, recommendations or comments, please do not hesitate to contact us.

Review this fact sheet to get acquainted with the individual stages of installation and with the necessary materials and tools you need to prepare.

Before you begin:

You can complete the installation with friends or with the help of a contractor. If you need help or guidance at each stage of the process, feel free to contact us by calling: **0898 461 906 and 0888 211 950**.

Keep the items in a clean place. It will be useful to arrange the panels on the ground in the order in which they will be installed. For gluing the panels, you will need a **class C2 cement adhesive**.

Useful tools: a small smooth **trowel or spatula** for applying the adhesive and for grouting.

Prepare the installation site:

An important condition to install your outdoor appliance correctly and easily is the installation site. It should be **even and leveled**.

Check the ground beneath as well as the walls in case you will be attaching the appliance to them. We recommend a base made of concrete, paving tiles or leveled natural stone slabs.

We do not recommend installing the outdoor appliance directly on grass, because the foundations could sink and distortions could emerge over time.

Installation:

The elements of the barbecue are arranged following the numbering on the attached scheme. Remember to **level horizontally and vertically** at each stage of installation.

Start with the base - the lower panels №1, 2 and 3. Install **the front lower panel №1 in front of the two side panels with №2** so that the sides fit inside between the front and rear panels. (If the base is equipped with a shelf, the side panels are also installed on the inside of the rear panel and fastened with metal studs.)

Before applying the adhesive, **wash and moisten the attachment points with plenty of water**.

Then apply a not very thick layer of cement adhesive along the entire edge in order to obtain 100% contact surface. Use a smooth trowel to spread the adhesive solution and remove the excess amount. The aim is to apply the adhesive as evenly as possible on the work area. When the panels come into contact with the strips of adhesive, you need to press to achieve adhesion without cavities. The panels are tightened with wire, belt or foil and there is no need to wait before proceeding with the above elements.

Raimar Ltd. since 1993 – Kresna city 2840 - tel.: + 359 898 461 906 - www.raimar.bg
Natural Stone Processing and Garden Equipment Manufacturing

Finally, grout:

Grouting is an important stage because it will guarantee you the beauty and cleanliness of your outdoor appliance.

Use the same mixture with the cement adhesive. First, thoroughly clean the joints themselves of any residue adhesive by moistening the joints lightly with a wet sponge without filling them with water. With diagonal movements apply the grout evenly to the visible joints using a rubber spatula. Then remove the residue. Once the grout starts to dry slightly, clean the surface with a slightly damp sponge and a wet cloth.

After the adhesive dries (1 to 2 days depending on the season), your new outdoor appliance is ready for use.

Maintenance and cleaning:

To keep them in perfect condition, clean on time (immediately after contamination) and maintain the surfaces of your outdoor appliances clean. Use suitable cleaning solutions, intended for the purpose. Natural stone usually requires little maintenance and grease stains weather over time. If necessary, a cleaning solution can be made using household detergent.

We recommend sealing the surfaces once a year with a protection solution of the German company Akemi: **No Stains Sealer**, which protects not only against water, but also against the absorption of oils.

We suggest covering the outdoor appliances with a blanket or nylon during the colder months to protect surfaces from ice.

We do not recommend using the countertops for heavy physical work with non-compliant mechanical tools.

We will be very grateful if you send some nice photos for advertising purposes to info@raimar-bg.com, Viber (+359 898 461 906) or Facebook: @RaimarBulgaria. As a token of gratitude, we will send you a **granite/marble cutting board as GIFT** :)!
Thank you for choosing a Bulgarian product!

IMPORTANT: BASIC SAFETY AND USE STANDARDS

The barbecues manufactured by Raimar meet the requirements of the international standard UNI EN 1860-1 /BDS EN 1860-1: 2013 + A1: 2017 "Devices, solid fuels and kindling for barbecue. Part 1: Barbecues, using solid fuels. Requirements and testing methods."

The customer shall have the right to use the legal warranty as provided for in Directive 1999/44 / EC of 25 May 1999 / EC of the EEC if they conscientiously comply with the rules set out in the Raimar instructions and in particular:

- always use the product as intended;
- always perform timely and careful maintenance.

Failure to follow the recommendations of Raimar's instructions will invalidate the warranty.

The manufacturer shall reject all direct and indirect civil and criminal liability for:

- installation that does not comply with the current laws in the country and safety directives;

- non-compliance with the instructions;
- installation by unqualified and untrained personnel;
- use which does not comply with the safety directives;
- modifications and repairs not authorized by the manufacturer;
- use of non-original or non-specific spare parts for the products;
- non-adequate frequency of maintenance;
- extraordinary circumstances or events.

Make sure that the place of installation of the product corresponds to all local, national and European provisions. Always use personal protective equipment provisioned by the law during installation.

It is possible that the elements have small differences in size, which are acceptable due to the type of material. These need to be corrected during installation and are not accepted as a complaint.

The efflorescence of concrete is not considered a complaint because it is a natural phenomenon that occurs as white spots on the cement panels. It is due to humidity (rain, snow, etc.) and may be more common in some very humid climates. Usually white spots dissolve from the rain within 2 years. To prevent this process, use concrete and stone sealers, which protect the surface of the products against moisture.

The product should be used by responsible adults who have the necessary technical knowledge for performing routine maintenance.

The wooden, cardboard and styrofoam parts of the packaging must be sent for recycling to local recycling centers.

This product complies with the CEE 2004 directive on general product safety, in particular in respect of materials which are in contact with foodstuffs.

WARNING! Do not use alcohol or petrol for ignition or re-ignition! Use only kindling for ignition of solid fuels for use in barbecue, complying with EN 1860-3!

Use the barbecues and ovens to cook food outdoors.

To avoid unpleasant smoke inconveniences and for proper use, there should be no obstacles, such as trees, buildings, etc. at a distance of less than 6 meters from the chimney.

According to the current standards UNI EN 1860-1, on certain aspects of the sale of consumer goods and their associated warranties, cracks may appear, but they do not affect the quality and the operation of the product and cannot be considered as warranty claims as they are the result of normal expansion due to heat.

Keep an eye on the fire, do not touch the hot spots and do not bring easily flammable objects near the hearth.

Always use appropriate safety equipment when working with the grill or oven.

Make sure that children playing nearby do not get close to barbecues and ovens while they are working.

WARNING! Do not step on or sit on the countertop!

WARNING! This barbecue or oven can get very hot!

WARNING! Keep children and animals at a safe distance!

Do not use your barbecue to burn leaves, grass or other household waste.